

PRODUCT DATA SHEET

NORGLASS LABORATORIES PTY.LTD.

A.B.N. 92 001 807 245
P.O. Box 312, Neutral Bay. NSW 2089 Australia
59 Moxon Road, Punchbowl NSW
Ph: 61 2 9708 2200 Fax: 61 2 9796 3069
Email: norglass@bigpond.net.au
www.norglass.com.au



NORTHANE CLEAR GLOSS

DESCRIPTION: A 2 pack, non-yellowing, polyurethane with outstanding chemical and abrasion resistance. Water clear when cured. Excellent gloss retention and fade resistance under extreme weather conditions.

USES: Aircraft exteriors, boats, buses, earthmoving equipment, anti-graffiti applications, hospital walls and floors, furniture, fish ponds and food surfaces. Ideal on timber, steel, aluminium and fibreglass as a durable waterproof, finish coat.

PROPERTIES (at 20°C)

COLOUR:	Water clear.
TOXICITY:	Toxic – see Precautions
FINISH:	Exceptionally high gloss. Also available in satin by using Norglass Flattening Agent (See data sheet)
COVERAGE:	Up to 12sq.metres/mixed litre
DRYING TIME:	Touch dry 1 hour. Recoat after 16 hours. Hard dry 48 hours
RECOATING:	Spraying: wet on wet technique Brush/Roller: After 16 hours
POT LIFE:	8 hours
MIXING RATIO:	2 parts Northane base to 1 part Northane hardener by volume
THINNING:	Spraying: Northane Spraying Thinners 33 1/3% at 50-70 P.S.I or according to the pressure system used. Brushing: Northane Brushing Thinners up to 3%
WEIGHT/LITRE:	1.065kg when mixed.
VOLUME SOLIDS:	40%
FLASH POINT:	32°C

- CLEAN UP:** NORGLASS SPRAYING THINNERS OR NORTHANE BRUSHING THINNERS.
- U.N. NUMBER:** 1263
- PREPARATION:** Northane Clear Gloss should only be applied over sound surfaces, cracked varnishes should be removed completely.
Recoating old Northane surfaces require degreasing and a light sand to a flat finish before proceeding.
Note: All surfaces to be finished in NORTHANE CLEAR should be thoroughly cleaned down to remove any traces of waxes, polishes and oils.
Where silicone polish has been used previously consult NORGLASS TECHNICAL ADVISORY DEPT on (02) 9708 2200 for the best method of removal, and read the Norglass directions on appropriate label specifications and M.S.D.S. on this product before use.
- APPLICATION:** Mix two parts of Northane Clear base with 1 part Northane hardener by volume and allow to stand for 10 minutes.
Add the appropriate thinner for brush or spray and strain into a pot or clean container. Leave for a further 10 minutes before use.
Do not apply Northane after 11am in winter unless the surface is protected from dew by a roof or is applied inside.
Northane Clear may be sprayed using a wet on wet technique, of multiple coats per day. Allow 48 hours to cure before handling as the clear will mark with pressure.
When completed, the surface should **not be cut or buffed** as the finish cannot match the original gloss level.
- TRANSPORTATION:** Flammable liquid. HAZCHEM 3[Y] P.G.III
Dangerous Goods Class 3.2
Pack sizes available: 4litre, 2litre, 1litre and 500ml
- PRECAUTIONS:** Provide adequate ventilation during use. Avoid breathing fumes.
Spray mist must not enter the operator's breathing zone.
Wear an air fed face mask when spraying as breathing of vapour is likely to be dangerous.
Do not use if you have ever had breathing difficulties after using paints containing ISOCYANATES (or with a head or chest cold).
Do not smoke and keep away from naked flame.
Wear protective gloves, goggles and clothing during use.
- FIRST AID:** If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 13 11 26 or (NZ) 0800 764 766 and have label information ready.
If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. If skin contact causes irritation, remove contaminated clothing and wash skin thoroughly. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.
- SPECIAL INSTRUCTIONS:** DO NOT USE THIS PRODUCT UNLESS ALL RECOMMENDATIONS ARE FOLLOWED.
Where Northane Clear is used on areas of constant immersion, 72 hours should elapse after the final coat before immersing.
Where Northane Clear is to be left to full exposure of the sun, multiple coats will be required to give U/V resistance. As a guide 6-8 coats would be recommended.
Read the Norglass guide on "The Good Oil on Clear Coatings" for additional advice.